

Using a Temporary Rail Bond Approval Form

Introduction

Only a Signals Engineer or delegate may authorise the use of temporary rail bonds.

The Signals Engineer or delegate use an *NRF 013 Temporary Rail Bond Approval* to record this approval.

Numbering forms

The Signals Engineer or delegate authorising the temporary rail bond approval must number the form consecutively on a *pad-by-pad* basis.

Mandatory items

All items must be completed:

- 1 Reference Number
- 2 Temporary rail bond details
- 3 Reason for temporary rail bond
- 4 Affected equipment
- 5 Requested by
- 6 Approved by

Network Forms

NRF 013 Temporary Rail Bond Approval

Effective date

14 May 2023

