

20

weekly notice

Monday, 19 May 2014
Sunday, 25 May 2014



Safeworking information, such as Weekly Notices and SAFE Notices, is available on the RailSafe website.

By accessing Weekly Notices and SAFE Notices online, you will receive safety information more quickly. Weekly Notices remain on the RailSafe website for two years; Permanent and Temporary SAFE Notices remain online as long as they are current.

Anyone needing back issues of Weekly Notices and SAFE Notices should contact the Network Rules unit.

If you are outside Sydney Trains, you can reach the RailSafe website via the following address:

www.railsafe.org.au

Other Safeworking documents, such as Network Rules, Network Procedures, Network Local Appendices, Safeworking Policies, SafeTracks flyers, and contractor information are also available online.

*GROUP MANAGER RULES AND COMPLIANCE
SYDNEY TRAINS*

CONTENTS

PUBLICATION DEADLINES AND SUBMISSION OF ARTICLES	2
LIDCOMBE (CENTRAL INNER WEST) – RENEWAL OF 713 AND 714 POINTS	3
CLYDE CONNECTION WORKS PROJECT – INSTALLATION OF 683B POINTS	4
GOSFORD PASSING LOOP – INSTALLATION OF 201B AND 202B POINTS	5
EDGECOMBE – 6A/B AND 7A/B POINTS TURNOUT RENEWAL	6
EMU PLAINS TO VALLEY HEIGHTS – PROVISION OF SIGNAL KEY SWITCH BOXES ON 38.9 AND 42.6 SIGNALS	7
SYDNEY CENTRAL (EAST AREA) – CONVERSION OF SIGNALS SY394, SY398 AND SY402 SIGNALS TO LED TYPE	8
GLENFIELD JUNCTION – COMMISSIONING OF GLENFIELD TRANSPORT INTERCHANGE PROJECT (DIAGRAM)	9
STATUS OF TOM NOTICES	19
STATUS OF PERMANENT SAFE NOTICES	21
STATUS OF NETWORK MANUALS AND FORMS	23
REQUESTS FOR NETWORK MANUALS AND FORMS	26
DISTRIBUTION OFFICERS	27
DISTRIBUTION OFFICER CONTACT FORM	30

PUBLICATION DEADLINES AND SUBMISSION OF ARTICLES

Dates of the next four Weekly Notices and deadlines for articles are:

Weekly Notice	For Week	Deadline
21	26/5/14–1/6/14	13/5/14
22	2/6/14–8/6/14	20/5/14
23	9/6/14–15/6/14	27/5/14
24	16/6/14–22/6/14	3/6/14

So that printing and distributing schedules can be met, it is essential articles are received by the deadline.

Late articles will be published in the next issue of the Weekly Notice. This may result in information not being distributed in time for it to be acted upon.

When submitting articles, please include your name, position title, telephone numbers and email details at the end of the articles as shown below:

Jemma Hossain

Network Rules Specialist

Tel: 02 8922 4590 (external) 2 4590 (internal)

Email: jemma.hossain@transport.nsw.gov.au

LIDCOMBE (CENTRAL INNER WEST) – RENEWAL OF 713 AND 714 POINTS

Commencing at 0200 hours on **Saturday, 24 May 2014**, and continuing until 0200 hours on Monday, 26 May 2014, the following work will be carried out:

- Existing 713 points (Down Suburban) will be replaced with a D84M MKIII type points machine and will be relocated approximately 0.1 metres away from Lidcombe Station.
- Existing 714 points (Up Suburban) will be replaced with a D84M MKIII type points machine and will be relocated approximately 0.01 metres closer to Lidcombe station.
- Existing Emergency Switch Machine Lock (ESML) for both 713 and 714 points will be replaced with the new Emergency Operation Lock (EOL) of the fortress key type at the same location.

VER24042014

Rodney Hyatt

Commissioning Engineer

Signal Works & External Resources

Tel: 02 9752 6133 (external) 2 6133 (internal)

Email: rodney.hyatt@transport.nsw.gov.au

Bryce Robilliard

A/Signal Design Engineer

Signalling & Control Systems

Engineering and Systems Integrity

Maintenance

Tel: 02 8922 1759 (external) 2 1759 (internal)

Email: bryce.robilliard@transport.nsw.gov.au

CLYDE CONNECTION WORKS PROJECT – INSTALLATION OF 683B POINTS

Commencing at 0200 hours on **Monday, 26 May 2014**, 683B turnout will be installed, detected, clipped and locked at 20.460km on the Down Relief line at Clyde. The points will be booked out of use until further notice.

Further information on this project can also be obtained from contacts below;

Ben Clay

Construction Manager

John Holland

Mob: 0410 303 085

Email: ben.clay@jhg.com.au

Arvind Chaluvaiiah

Rail Interface Manager

John Holland

Mob: 0418 270 468

Email: arvind.chaluvaiiah@jhg.com.au

GOSFORD PASSING LOOP – INSTALLATION OF 201B AND 202B POINTS

Since **Sunday ,18 May 2014**, the following work was carried out:

- Installation of 201 B points on the Down Main line.
- Installation of 202 B Points on the Up Main line.

201B points were clipped, spiked and XL locked normal.

202B points were clipped, spiked, XL locked and detected normal.

The Control and indication panels at Gosford Signal box will remain unaltered at this stage. Panels will be amended during the final commissioning to reflect the final layout.

VER 6042014

Jarrad Kircher

Signalling Manager GPL

Downer

Mob: 0427 229 714

Email: jarrad.kircher@downergroup.com

Jason Eadie

Senior Signalling Engineer

Parsons Brinckerhoff

Tel: 02 9200 0930

Email: jeadie@pb.com.au

EDGECOMBE – 6A/B AND 7A/B POINTS TURNOUT RENEWAL

Commencing at 0200 hours on **Saturday, 31 May 2014**, and continuing until 0200 hours on Monday, 2 June 2014, the following work will be carried out:

- The existing turnouts – 6 and 7 Points at Edgcombe will be renewed. The point mechanisms will be replaced with Westinghouse D84M MKIII type utilising an in-bearer Spherolock arrangement.
- 6A end will be relocated approximately 700mm towards Sydney and 6B end relocated approximately 700mm towards Lithgow.
- 7A end will be relocated approximately 700mm towards Sydney and 7B end relocated approximately 800mm towards Lithgow.
- The existing Emergency Switch Machine Lock (ESML) equipment will be replaced with new Emergency Operations Lock (EOL) equipment of the fortress key type and retained in the existing location.

VER06032014

Garry Leamey

Senior Signal Engineer

Metro West, Signal Maintenance

Tel: 02 4780 3969

Mob: 0419 206 228

Email: garry.leamey@transport.nsw.gov.au

Donovan Dhondee

Signal Design Engineer

Sydney Trains

Tel: 02 8922 1502

Mob: 0413 172 353

Email: donovan.dhondee@transport.nsw.gov.au

EMU PLAINS TO VALLEY HEIGHTS – PROVISION OF SIGNAL KEY SWITCH BOXES ON 38.9 AND 42.6 SIGNALS

Commencing at 0700 hours on **Saturday, 31 May 2014**, and continuing until 2400 hours on Sunday, 1 June 2014, the following work will be carried out:

Signal Key Switch boxes will be mounted on the signals as stated above. The worksite protection key is located within. When the box is unlocked and the door opened, the following instruction sign is displayed facing the driver:



The worksite protection keys will be inscribed as follows:

- 38.9: '38.9 Down Main 63.084km to 67.551 km'
- 42.6: '42.6 Up Main 68.296km to 63.898km'

The extent of each worksite area is identified by signs inscribed with the above kilometrage. An example of the inscription is as follows:



VER08112013

Jesse Crick

Project Engineer

Programme Manager Signals Control and Electrical

Mob: 0408292819

Peter McAlister

Senior Signal Design Engineer

Tel: 02 8922 1732 (external) 2 1732 (internal)

Email: peter.mcalister@transport.nsw.gov.au

SYDNEY CENTRAL (EAST AREA) – CONVERSION OF SIGNALS SY394, SY398 AND SY402 SIGNALS TO LED TYPE

Since 0200 hours on **Monday, 28 April 2014**, the following work was carried out.

The existing Signals SY398 on the Up Airport line (SR) and SY394, SY402 on the Up Local (UL) were converted to LED type lamps.

The indications displayed and the form of signals remain the same.

VER29042014

Rick Maranik

Commissioning Manager

Sydney Trains

Tel: 36 544

Mobile: 0412 520 793

Email: richard.maranik@transport.nsw.gov.au

Darren Martin

Design Technical Specialist

Sydney Trains

Tel: 02 89221736 (external) 21 736 (internal)

Email: darren.martin2@transport.nsw.gov.au

GLENFIELD JUNCTION – COMMISSIONING OF GLENFIELD TRANSPORT INTERCHANGE PROJECT

Commencing at 0200 hours on **Saturday, 7 June 2014**, and continuing until 0200 hours on Tuesday, 10 June 2014, the following signalling alterations will be carried out:

- New and altered yard limit boards, signals, points, train stops and guard's indicators will be provided. All new signals and guard's indicators will be of LED type.
- Glenfield Platform 4 will be brought into use.

The new signalling equipment will be controlled from the Sydenham Control Centre. A new Microlok II Interlocking will replace the existing Glenfield area Solid State Interlocking (SSI).

The system of safe working is Rail Vehicle Detection.

A driver's diagram showing the new arrangements is included in this Weekly Notice.

Details of the changes are as follows.

New and altered Lines brought into use

- The Down East Hills will be extended from 41.082 km and connect to Down Main with connections via Crossover 50 (41.101 km) and Crossover 53 (41.384 km). The Down East Hills will then continue via Platform 4 and will connect to the existing Down Main with a new connection at Turnout 57 (42.683 km).
- The Up East Hills will be extended to a new origin at new Turnout 58 (42.683 km) where it connects to the Up Main. The Up East Hills continues through Platform 1 and reconnects to the Up Main through Crossover 52 (41.331 km) and Crossover 54 (41.453 km). The new section of Up East Hills will cross the Up Main and Down Main via a new flyover and connect to the existing Up East Hills at 31.444 km (East Hills kilometrage).
- The Down Leppington Main will be connected to the Down East Hills with connection via Crossover 62 (42.056 km) and to the Down Main with connection via Crossover 60 (42.022 km)

Continued on the next page

Continued from the previous page

- The Up Leppington Main will be connected to the Up East Hills with connection via Crossover 61 (42.025 km) and to the Up Main with connection via Crossover 63 (42.041 km)
- The current turnback facility from the Down Main to Platform 1 will be removed. Terminating trains from the Down Main will use Platform 3 and return to the Up Main via new Crossover 56 (41.811 km)
- Platform 1 will be normally used for up direction movements to the Up East Hills.
- Platform 2 will be normally used for up direction movements along the Up Main and from the Up Leppington Main to the Up Main.
- Platform 3 will be normally used for down direction movements along the Down Main. Glenfield Platform 3 will also cater for turnback moves from the Down Main prior to the commencement of commissioning of the Glenfield to Leppington Line and for emergency use in the future.
- Platform 4 will be normally used for down direction movements from the Down East Hills and also down direction movements from the Down Main when Platform 3 is in turnback operation.

Stop Blocks

Existing stop block will be removed as shown in the table below:

Kilometre (Approx)	Description	Remarks
41.220	New Up East Hills	Existing stop block removed
41.210	New Down East Hills	Existing stop block removed
42.100	New Up East Hills	Existing stop block removed
42.100	New Up Leppington Main	Existing stop block removed
42.520	New Down East Hills	Existing stop block removed
42.550	New Up East Hills	Existing stop block removed

Continued on the next page

Continued from the previous page

Signals

The final arrangements are shown on the Glenfield Drivers Diagram published in this weekly notice.

The new signals will display indications in accordance with the Network Rules.

Yard limit boards and end of yard limit boards are installed on GD1, GD3, EH19.80, 25.4, 26.7, GD40, GL42.5 and GD42 signals.

Signal Routes and Designations

All signals listed in the following tables are new signals and aspects are LED type.

Down Main Signals

Signal	Route	Description	Route Indicator	Remarks
GD3	3(M)	Down Accept – Down Main	-	Left Hand Turnout Repeater provided. Fitted with Horizontal YL & EYL Boards.
GD7	7(M)A	Down Home – Down Main to Down East Hills	-	Aspect restricted to medium turnout aspect.
	7(S)A	Shunt – Down Main to Down East Hills	EH	Stencil Route Indicator provided.
	7(M)B	Down Home – Down Main	-	Preliminary Medium provided for turnout to Leppington line. Left Hand Turnout Repeater provided.
	7(S)B	Shunt – Down Main	DM	Stencil Route Indicator provided.
GD13	13(M)	Down Home – Down Main	-	Left Hand Turnout Repeater provided. Conditionally cleared unless 23(M)A, 23(S)A, 23(M)B or 23(S)B is set.
	13(S)	Shunt – Down Main	-	
GD23	23(M)A	Down Home Starting – Down Main to Down Leppington Main	-	Aspect restricted to medium turnout aspect. 23(M)A installed but not brought into use in SWRL stage 1.
	23(S)A	Shunt – Down Main to Down Leppington Main	LN	Stencil Route Indicator provided. 23(S)A installed but not brought into use in SWRL stage 1.
	23(M)B	Down Home – Down Main	-	
	23(S)B	Shunt – Down Main	DM	Stencil Route Indicator provided.
GD35	35(M)	Down Home Starting – Down Main	-	
	35(S)	Shunt – Down Main	-	
26.7	26.7	Automatic – Down Main	-	Fitted with Horizontal YL & EYL Boards.

Continued on the next page

Continued from the previous page

Down East Hills Signals

Signal	Route	Description	Route Indicator	Remarks
GD1	1(M)	Down Accept – Down East Hills	-	Right Hand Turnout Repeater provided. Fitted with Horizontal YL & EYL Boards.
GD5	5(M)A	Down Home – Down East Hills	-	
	5(S)A	Shunt – Down East Hills	EH	Stencil Route Indicator provided.
	5(M)B	Down Home – Down East Hills to Down Main	-	Aspect restricted to medium turnout aspect.
	5(S)B	Shunt – Down East Hills to Down Main	DM	Stencil Route Indicator provided.
GD11	11(M)	Down Outer Home – Down East Hills	-	Right Hand Turnout Repeater provided. Conditionally cleared unless 21(M)A, 21(S)A, 21(M)B or 21(S)B is set.
GD21	21(M)A	Down Home – Down East Hills	-	
	21(S)A	Shunt – Down East Hills	EH	Stencil Route Indicator provided.
	21(M)B	Down Home Starting – Down East Hills to Down Leppington Main	-	Aspect restricted to medium turnout aspect. 21(M)B installed but not brought into use in SWRL stage 1.
	21(S)B	Shunt – Down East Hills to Down Leppington Main	LN	Stencil Route Indicator provided. 21(S)B installed but not brought into use in SWRL stage 1.
GD33	33(M)	Down Home Starting – Down East Hills to Down Main	-	
	33(S)	Shunt – Down East Hills to Down Main	-	

Down Leppington Main Signals

Signal	Route	Description	Route Indicator	Remarks
GL42.5	GL42.5	Automatic – Down Leppington Main	-	Fitted with Horizontal YL & EYL Boards. GL42.5 signal installed but not brought into use in SWRL stage 1.

Continued on the next page

Continued from the previous page

Up Main Signals

Signal	Route	Description	Route Indicator	Remarks
GD40	40(M)	Up Accept – Up Main	-	Fitted with Horizontal YL & EYL Boards.
GD38	38(M)	Up Outer Home – Up Main	-	Left Hand Turnout Repeater provided.
GD36	36(M)A	Up Home - Up Main to Up East Hills	-	Aspect restricted to medium turnout aspect.
	36(S)A	Shunt - Up Main to Up East Hills	EH	Stencil Route Indicator provided.
	36(M)B	Up Home - Up Main	-	
	36(S)B	Shunt – Up Main	UM	Stencil Route Indicator provided.
GD24	24(M)	Up Home – Up Main	-	Left Hand Turnout Repeater provided.
	24(S)	Shunt – Up Main	-	
GD18	18(M)A	Up Home – Up Main to Up East Hills	-	Aspect restricted to medium turnout aspect.
	18(S)A	Shunt - Up Main to Up East Hills	EH	Stencil Route Indicator provided.
	18(M)B	Up Home – Up Main	-	
	18(S)B	Shunt – Up Main	UM	Stencil Route Indicator provided.
GD16	16(M)A	Up Home – Down Main to Up East Hills	E	Aspect restricted to medium turnout aspect. Multi Lamp Route Indicator (MLRI) provided. Co-Acting with Miniature Multi Lamp Route Indicator (MMLRI) provided.
	16(S)A	Shunt - Down Main to Up East Hills	EH	Stencil Route Indicator provided. Co-Acting with Miniature Multi Lamp Route Indicator (MMLRI) provided.
	16(M)B	Up Home – Down Main to Up Main	M	Aspect restricted to medium turnout aspect. Multi Lamp Route Indicator (MLRI) provided. Co-Acting with Miniature Multi Lamp Route Indicator (MMLRI) provided.
	16(S)B	Shunt - Down Main to Up Main	UM	Stencil Route Indicator provided. Co-Acting with Miniature Multi Lamp Route Indicator (MMLRI) provided.

Continued on the next page

Continued from the previous page

Up Main Signals (continued)

Signal	Route	Description	Route indicator	Remarks
GD16 CO-ACTING	16(M)A	Up Home – Down Main to Up East Hills	E	Tri-Colour LED lamps provided. Miniature Multi Lamp Route Indicator (MMLRI) provided.
	16(S)A	Shunt - Down Main to Up East Hills	E	Miniature Multi Lamp Route Indicator (MMLRI) provided.
	16(M)B	Up Home – Down Main to Up Main	M	Tri-Colour LED lamps provided. Miniature Multi Lamp Route Indicator (MMLRI) provided.
	16(S)B	Shunt - Down Main to Up Main	M	Miniature Multi Lamp Route Indicator (MMLRI) provided.
GD15	15(S)	Shunt – Up Main to Down Main	-	
GD8	8(M)	Up Home Starting – Up Main	-	
	8(S)	Shunt – Up Main	-	
25.4	25.4	Automatic – Up Main	-	Fitted with Horizontal YL & EYL Boards.

Up East Hills Signals

Signal	Route	Description	Route Indicator	Remarks
GD28	28(M)	Up Home – Up East Hills	-	Mounted on Cantilever.
	28(S)	Shunt – Up East Hills	-	Mounted on Cantilever.
GD20	20(M)	Up Home – Up East Hills	-	Right Hand Turnout Repeater provided. Mounted on Cantilever.
	20(S)	Shunt – Up East Hills	-	Mounted on Cantilever.
GD10	10(M)A	Up Home Starting –Up East Hills	-	
	10(S)A	Shunt –Up East Hills	EH	Stencil Route Indicator provided.
	10(M)B	Up Home Starting – Up East Hills to Up Main	-	Aspect restricted to medium turnout aspect.
	10(S)B	Shunt – Up East Hills to Up Main	UM	Stencil Route Indicator provided.
EH19.80	EH19.80	Automatic – Up East Hills	-	Fitted with Horizontal YL & EYL Boards.

Continued on the next page

Continued from the previous page

Up Leppington Main Signals

Signal	Route	Description	Route Indicator	Remarks
GD42	42(M)	Up Accept – Up Leppington Main	-	Right Hand Turnout Repeater provided. Fitted with Horizontal YL & EYL Boards. Low Speed Aspect provided. Aspect clearing 'G/R' requires ((26(M) A or 26(S)A) set with 28BT track clear or (26(M)B or 26(S)B) set with 24BT clear), with 42 ITS detected reverse. GD42 signal installed but not brought into use in SWRL stage 1.
GD26	26(M)A	Up Home - Up Leppington Main to Up East Hills	-	Mounted on Cantilever.
	26(S)A	Shunt – Up Leppington Main to Up East Hills	P1	Stencil Route Indicator provided. Mounted on Cantilever.
	26(M)B	Up Home – Up Leppington Main to Up Main	-	Aspect restricted to medium turnout aspect. Mounted on Cantilever.
	26(S)B	Shunt – Up Leppington Main to Up Main	P2	Stencil Route Indicator provided. Mounted on Cantilever.

Guards Indicators

The Glenfield Station Guards Indicators are configured as follows:

Platform	Guard Indicator Direction	Associated Signal
Platform 1	Up Indicators Only	GD20
Platform 2	Up Indicators Only	GD18
Platform 3	Up Indicators	GD16
	Down Indicators	GD23
Platform 4	Down Indicators Only	GD21

Intermediate Train Stop

Kilometre	Associated Signal	Line	Direction
42.430	GD42	Leppington Main	Up

Continued on the next page

Continued from the previous page

Points

Existing 41 turnout points from Down Main to Up East Hills will be removed.

Redundant 40, 42 and 44 points will be clipped, spiked, XL locked and detected to Normal position pending removal in a later stage.

The following table details the points that will be brought into use:

Points No.	Description (final arrangement)
50	Crossover, Down East Hills to Down Main.
52	Crossover, Up East Hills to Up Main.
53	Crossover, Down Main to Down East Hills
54	Crossover, Up Main to Up East Hills
56	Crossover, Down Main to Up Main.
57	Turnout, Down East Hills to Down Main
58	Turnout, Up Main to Up East Hills
60	Crossover, Down Main to Down Leppington Main
61	A – Up East Hills B – Up Leppington Main to Up Escape / Up East Hills
62	Crossover, Down East Hills to Down Leppington Main
63	Crossover, Up Leppington Main to Up Main

Emergency Operation of Points

Keyless type EOLs are provided for emergency control of points at Glenfield Junction as shown on the drivers diagram in this Weekly Notice. Operation of the EOL push buttons will move all ends of the corresponding points to the desired position. When using the EOL care must be taken to ensure that all ends of the points have operated correctly and the points are clipped and locked before any train is permitted to pass over them.

Continued on the next page

Continued from the previous page

Telephones

Telephones will be provided as shown on the Drivers Diagram in this weekly notice. All phones ring through to Sydenham Control Centre.

Emergency Working Override

An Override Switch Box is provided at Glenfield in the event of a loss of control of the Glenfield Junction interlocking from the Sydenham control centre.

When Override is enabled, all non-through routes will cancel. Through signal routes will set if not already set and auto-reclear after the passage of each train. Listed below are the Glenfield Junction control area through routes that will be set, when Override is enabled:

Line	Route
DOWN EAST HILLS /DOWN MAIN	1(M)
	5(M)A
	11(M)
	21(M)A
	33(M)
UP MAIN/ UP EAST HILLS	40(M)
	38(M)
	36(M)A
	28(M)
	20(M)
	10(M)A
DOWN MAIN/ DOWN LEPPINGTON	3(M)
	7(M)B
	13(M)
	23(M)A
UP LEPPINGTON/ UP MAIN	42(M)
	26(M)B
	18(M)B
	8(M)

Continued on the next page

Continued from the previous page

The mode of operation of Glenfield Junction Override is selected by using the three position switch (AUTO/OFF/FORCED) located in a stainless steel box, XL locked, on the outside wall of location GD16.

OFF: Emergency override is disabled.

AUTO: When selected emergency override will be enabled when communication with the control system is lost for 180 seconds.

FORCED: When selected emergency override will be enabled.

(Note - AUTO and FORCED modes are disconnected and booked out of use until further notice)

Override switch and set indications are provided inside the override box at GD16 location. Override switch indication is provided on the ATRICS at Sydenham control centre.

VER 30042014
DRIVERS DIAGRAM VER 30042014

Scott Watson

Signalling Commissioning Engineer
Sydney Trains

Mob: 0408 475035

Email: scott.watson@transport.nsw.gov.au

Sathish Veerabadrappa

Signalling Engineer
Parsons Brinckerhoff/GJA

Tel: 0420 643374

Email: sveerabadrappa@pb.com.au

STATUS OF TOM NOTICES

Number	Title	Issued	Effective
001–2007	Introduction of TOM Notices	13/09/07	13/09/07
017–2007	Operating Instruction Manual for Hunter rail car	1/11/07	13/11/07
019–2007	MK16 Vigilance control on XPT power car	2/11/07	8/11/07
018–2007	Emergency equipment boxes RailCorp train fleet	1/11/07	19/11/07
004–2008	OMDT 450: Description and operation of XPT trains	1/5/08	11/5/08
008–2009	OMET 264: Minimum tractive effort requirements	1/10/09	11/10/09
010–2009	OMDT 461: XPT radio amalgamation unit (RAU)	26/11/09	6/12/09
011–2009	OMDT 462: XPT MetroNet radio	26/11/09	6/12/09
012–2009	OMDT 463: XPT CountryNet and local radios	26/11/09	6/12/09
013–2009	OMDT 464: MultiChannel radio	26/11/09	6/12/09
014–2009	OMDT 465: XPT train-to-base radio	26/11/09	6/12/09
001–2010	OMDT 458: Train preparation of XPT trains	18/2/10	28/2/10
010–2011	XPT 030: Minimum Operating Standards	28/7/11	7/8/11
015–2011	OMET 316: Defective Air Springs	24/11/11	4/12/11
001–2012	OMET 266: Operation of Y–Set Trains	2/2/12	12/2/12
004–2012	TWP 176: Wayside Train Condition Monitor Alarms	27/9/12	7/10/12
007–2012	TWP 203: Changing ends	25/10/12	4/11/12
008–2012	TWP 217: Train Operating System (TOS) Display Unit Failure	25/10/12	4/11/12
009–2012	TWP 233: Control Circuit Failures	25/10/12	4/11/12
010–2012	48 Class: Train Operations Manual (TOM)	25/10/12	4/11/12
011–2012	TWP 178: CountryNet and Local Radios	29/11/12	9/12/12
001–2013	Operation of H–Set (Oscar) Trains Fitted with Automatic Train Protection (ATP) Equipment	17/1/13	27/1/13

Continued on the next page

Continued from the previous page

Number	Title	Issued	Effective
003–2013	48 Class: Wheels	7/2/13	10/2/13
004–2013	TWP 188: Jumper Couplings	14/3/13	24/3/13
007–2013	TWP 184: Refuelling XPT, Explorer and Endeavour Trains	18/4/13	28/4/13
013–2013	OMDT 454: Disabled Train	23/5/13	2/6/13
010–2013	OMET 350: Operation And Management of Electric Trains-Standards	30/5/13	9/6/13
015–2013	OMET 200: Minimum Standards for Electric Trains	30/5/13	9/6/13
016–2013	TWP 100: Responsibilities Of Train Crews	30/5/13	9/6/13
017–2013	WAR 030: Minimum Standards	30/5/13	9/6/13
020–2013	TWP 152: Disabled Trains	21/11/13	1/12/13
021–2013	TWP 138: Assisting Trains Using Emergency Couplers	21/11/13	1/12/13
001–2014	Ammendment to OMET 200, OMET 350, WAR 030 XPT 030, OMDT 400 & OMDT 500 (Visibility Lights)	20/2/14	2/3/14
002–2014	OMET 220: Wheelslip light indications	20/2/14	2/3/14
005–2014	Operation of T-set (Tangara) trains fitted with ATP equipment	3/4/14	14/4/14
003–2014	Internal Emergency Door Release and Passenger Emergency Intercom Alarm.	10/4/14	20/4/14
004–2014	TWP 114: Train Crew Member Leaving or Returning to the Crew Compartment.	10/4/14	20/4/14
006–2014	WAR 202: Bogie Faults	24/4/14	4/5/14
007–2014	WAR 001: Stabling	24/4/14	4/5/14

Jemma Hossain

Network Rules Specialist

Tel: 02 8922 4590 (external) 2 4590 (internal)

Email: jemma.hossain@transport.nsw.gov.au

STATUS OF PERMANENT SAFE NOTICES

Number	Title	Issued	Effective
104-2013	Network Rules – Network Procedures	21/11/13	1/12/13
120-2013	NLA 618: Chullora	21/11/13	2/12/13
121-2013	NLA 616: Enfield	21/11/13	2/12/13
114-2013	NLA 320: Broadmeadow – Newcastle	28/11/13	12/12/13
108-2013	NLA 306: North Sydney	5/12/13	15/12/13
123-2013	NLA 402: Sydenham	5/12/13	15/12/13
125-2013	NLA 500: Lidcombe - Campbelltown	5/12/13	15/12/13
127-2013	NLA 208: Blacktown	5/12/13	15/12/13
126-2013	Metropolitan Freight Network (MFN) – ARTC Assume Signalling Control Function of Enfield	5/12/13	16/12/13
109-2013	NLA 416: Wollongong	12/12/13	22/12/13
110-2013	OSP 3: Protection Arrangements for Repairing Trains in Service	12/12/13	22/12/13
111-2013	OSP 23: Responding to Wayside Train Condition Monitoring Alarms	12/12/13	22/12/13
112-2013	Trial of New Speed Signs in the Sydney Trains Network	12/12/13	22/12/13
115-2013	NLA 608: Port Kembla	12/12/13	22/12/13
116-2013	NLA 502: Sefton Park Junction	12/12/13	22/12/13
117-2013	NLA 212: Penrith – Wallerawang	12/12/13	22/12/13
118-2013	NLA 504: Campbelltown	12/12/13	22/12/13
007-2014	Exception to TWP 108: Route Knowledge	19/12/13	3/1/14
001-2014	Network Rules – Network Forms – Network Procedures	9/1/14	19/1/14
002-2014	NLA 202: Clyde Down Sidings	9/1/14	19/1/14
003-2014	NLA 206: Clyde and Granville	9/1/14	19/1/14
004-2014	NLA 312: Gosford	9/1/14	19/1/14
005-2014	Worksite Handsignaller Ahead Signs NSG 604	9/1/14	19/1/14
006-2014	NLA 318: Broadmeadow – Woodville Junction	9/1/14	19/1/14
008-2014	NTR 406: Using Train Lights	23/1/14	2/2/14
009-2014	NSG 608: Passing Signals at Stop	23/1/14	2/2/14
016-2014	NLA 102: Sydney Terminal	30/1/14	9/2/14
011-2014	NLA 104: City Circle	6/2/14	16/2/14

Continued on the next page

Continued from the previous page

Number	Title	Issued	Effective
012–2014	NLA 100: Central	6/2/14	16/2/14
013–2014	NLA 110: Central - Lidcombe	6/2/14	16/2/14
017–2014	NLA 314: Gosford - Broadmeadow	6/2/14	16/2/14
018–2014	NLA 400: Central - Sutherland	6/2/14	16/2/14
015–2014	NLA 316: Sulphide Junction	6/2/14	16/2/14
020–2014	NLA 304: Central – Hornsby	13/2/14	23/2/14
021–2014	NLA 310: Hornsby – Gosford	13/2/14	23/2/14
014–2014	NLA 214: Lithgow	20/2/14	2/3/14
022–2014	Spenco Ultrasonic Testing	20/2/14	2/3/14
023–2014	NLA 410: Sutherland - Wollongong	20/2/14	2/3/14
027–2014	NLA 508: Sydenham - Sefton Park Junction	20/2/14	2/3/14
035–2014	Southern Sydney Freight Line (SSFL) – Shared Corridor Protocols	13/3/14	23/3/14
026–2014	NLA 116: Flemington	13/3/14	23/3/14
029–2014	NLA 300: Strathfield – Hornsby	20/3/14	31/3/14
030–2014	Procedures for Trains Entering - Departing Macdonaldtown stabling yard	27/3/14	6/4/14
031–2014	NLA Explanatory notes	27/3/14	6/4/14
032–2014	NLA Introduction	27/3/14	6/4/14
033–2014	NLA 420 Bomaderry (Nowra)	27/3/14	6/4/14
034–2014	NLA 114: Strathfield	27/3/14	6/4/14
039–2014	NLA 108: Central - Sydenham (via Green Square)	3/4/14	13/4/14
038–2014	NLA 510: Sydenham - Glenfield	10/4/14	20/4/14
041–2014	NLA 200: Lidcombe - Penrith	10/4/14	20/4/14
028–2014	Trial of Signal Key Switches	27/4/14	26/10/14
036–2014	NWT 304: Track Occupancy Authority	27/4/14	26/10/14
037–2014	NPR 701: Using a Track Occupancy Authority	27/4/14	16/10/14
042–2014	NLA 418: Wollongong - Bomaderry (Nowra)	1/05/14	11/05/14
044–2014	Worksite Protection Plan – Tablet Version Trial	1/05/14	11/05/14
045–2014	NLA 302: Hornsby	14/11/13	24/11/13

Jemma Hossain

Network Rules Specialist

Tel: 02 8922 4590 (external) 2 4590 (internal)

Email: jemma.hossain@transport.nsw.gov.au

STATUS OF NETWORK MANUALS AND FORMS

Network Manuals

Title	Status Sheet	Date issued
--------------	---------------------	--------------------

Network Rules

General	9	July 2012
Work on Track	12	July 2012
Train Working	8	July 2012
Systems of Safeworking and Special Working	5	July 2012
Signals and Signs	9	July 2012
Glossary	8	July 2012

Network Procedures

Procedures	12	July 2012
Forms	8	July 2012

Note, when filing your Network Rules and Procedures they should be comprised of the following amendment packs:

- August 2005 (Total reprint)
- May 2007
- November 2008
- June 2010
- December 2010
- July 2012 (Latest amendment packs. Note, 2 packs were issued)

Network Local Appendices

Network Local Appendices	9	Dec 2012
--------------------------	---	----------

Title	Version	Date issued
--------------	----------------	--------------------

Operator Specific Procedures

OSP 3	8	May 2012
OSP 4	4	Sept 2009
OSP 5	5	Sept 2009

Continued on the next page

Continued from the previous page

Title	Version	Date issued
OSP 6	4	Sept 2009
OSP 7	6	May 2012
OSP 8	3	Sept 2009
OSP 9	5	May 2012
OSP 10	3	Sept 2009
OSP 11	6	May 2012
OSP 12	6	Sept 2009
OSP 13	3	Sept 2009
OSP 14	6	May 2012
OSP 15	5	Sept 2009
OSP 16	6	May 2012
OSP 17	3	Sept 2009
OSP 18	5	Sept 2009
OSP 19	3	Sept 2009
OSP 20	4	May 2012
OSP 21	5	May 2012
OSP 22	2	Sept 2009

Train Working Procedures

TWP 100 (New)	3	May 2012
TWP 102 (New)	3	May 2012
TWP 106	3	May 2012
TWP 108 (New)	4	May 2012
TWP 110	3	May 2012
TWP 112	3	May 2012
TWP 114	3	May 2012
TWP 116	3	May 2012
TWP 118 (New)	3	May 2012
TWP 120	3	May 2012
TWP 122	3	May 2012
TWP 124	3	May 2012
TWP 126	3	May 2012
TWP 128 (New)	3	May 2012
TWP 130	3	May 2012
TWP 132	3	May 2012
TWP 134	3	May 2012
TWP 136 (New)	3	May 2012
TWP 138	3	May 2012

Continued on the next page

Continued from the previous page

Title	Version	Date issued
TWP 142	3	May 2012
TWP 144	5	May 2012
TWP 146	3	May 2012
TWP 148	3	May 2012
TWP 150	3	May 2012
TWP 152	4	May 2012
TWP 154	3	May 2012
TWP 156 (New)	5	May 2012
TWP 158	3	May 2012
TWP 160 (New)	3	May 2012
TWP 162	3	May 2012
TWP 164 (New)	4	May 2012
TWP 166	3	May 2012
TWP 168 (New)	3	May 2012
TWP 170	3	May 2012
TWP 172	4	May 2012
TWP 174 (New)	1	May 2012

Network Forms

Title	Form version	Date issued
NRF 000 General Information	N/A	Dec 2010
NRF 002 Track Occupancy Authority	5	Aug 2005
NRF 003 Infrastructure Booking Authority	3	Aug 2005
NRF 004 Condition Affecting the Network	2	Aug 2005
NRF 005 Special Proceed Authority	3	July 2012
NRF 007 Pilot Staff Ticket	2	Aug 2005
NRF 008 Pilot Staff Notice	2	Aug 2005
NRF 010 Pilot Staff Working Introduction	2	Aug 2005
NRF 011 Worksite Warning	2	Aug 2005
NRF 012 Checklist for an Unsignalled Movement within Consolidated Yard Limits	2	Aug 2005
NRF 013 Temporary Rail Bond Approval	2	Aug 2005
NRF 014 Pre-work Briefing	2	July 2012
NRF 015A Worksite Protection Plan	2	July 2012
NRF 015B Worksite Protection Plan for Lookout Working	2	July 2012
NRF 016 Protection Officer's Log Book	1	Dec 2010
NRF 017 Protection Officer's Diary	1	Dec 2010

REQUESTS FOR NETWORK MANUALS AND FORMS

Please regularly check that your Network Manuals and Forms are up to date and include the current status sheet numbers for each section, as listed in this Weekly Notice.

If your manuals do not have the correct status sheets, they have not been properly amended and the Safeworking information will not be up to date.

All Sydney Trains staff issued with Network Manuals and who require regular updates and amendments need to contact their relevant distribution officer, as listed in this Weekly Notice, to have their name and contact details included in the distribution list. This will ensure that you receive all updated Network Manuals and Forms.

All requests to receive Safeworking documentation must be forwarded through your controlling officer to the appropriate distribution officer.

Those outside Sydney Trains can access Safeworking information by visiting the RailSafe website at www.railsafe.org.au

External users who wish to purchase hard copies of the Network Rules and Network Procedures can download an order form from the RailSafe website under Contractors on the top menu bar.

DISTRIBUTION OFFICERS

Sydney Trains

Safety and Environment

Maria Economou

Safety Support

Tel: 2 4502 Fax: 2 1840

Email: Maria.Economou@transport.nsw.gov.au

Engineering and Projects

Teresa Sitjar

Chief Engineer— Signals

Tel: 2 1769 Fax: 2 1650

Email: Teresa.Sitjar@transport.nsw.gov.au

John Lesiw

Geotechnical Services

Tel: 2 7511 Fax: 2 7786

Email: John.Lesiw@transport.nsw.gov.au

Suzanne Warner

Engineering Services— Professional Services

Tel: 6 2478 Fax: 6 2939

Email: Suzanne.Warner@transport.nsw.gov.au

Robert Nelson

PPP Rollingstock — Acquisition Strategy

Tel: 9 1441 Fax: 9 6500

Email: Robert.Nelson@transport.nsw.gov.au

Armando Ang

Data Analyst

Tel: 2 1214 Fax: 2 1726

Email: Armando.Ang@transport.nsw.com.au

Operations

James Mather

Area Manager - Hornsby

Tel: 36513

Paul Doherty

Area Manager - Central

Mob: 0419476346

Email: Paul.DOHERTY@transport.nsw.gov.au

Kamlesh Batra

Area Manager - Central/North Sydney

Mob: 0408196936

Email: KAMLESH.BATRA@transport.nsw.gov.au

Kamal Deo

Crew Manager PPP

Tel: 93964

Email: KAMAL.DEO@transport.nsw.gov.au

Fred Dangar

Area Manager - Blacktown/Penrith/Richmond

Mob 0407163087

Email: Fred.DANGAR@transport.nsw.gov.au

Paul Bartolo

Area Manager - Flemington

Mob: 0438466118

Email: PAUL.BARTOLO@transport.nsw.gov.au

Michael Dorrian

Area Manager - Mortdale/Cronulla/Waterfall

Mob: 0428214460

Email: Michael.DORRIAN@transport.nsw.gov.au

Roopali Khanna

Area Manager - Liverpool/Campbelltown

Mob: 0407149152

Email: ROOPALI.KHANNA@transport.nsw.gov.au

William Morrison

Signal Operations — South

Tel: 9 1057

Email: William.Morrison@transport.nsw.gov.au

Christine Menezes

Operations — Network Control — West

Tel: 8 7530 Fax: 8 7259

Email: Christine.Menezes@transport.nsw.gov.au

Greg Oxley

Operations — Rail Management Centre (RMC)

Tel: 9 4255 Fax: 9 4438

Email: Greg.Oxley@transport.nsw.gov.au

Petar Majstorovic

Incident Rail Commander

Tel: 9 1590 Fax: 9 1770

Email: Petar.Majstorovic@transport.nsw.gov.au

Ashraf Riyadh

Sector 1 — Customer Service — Illawarra

Tel: 2 7728 Fax: 02 95637728

Email: Ashraf.Riyadh@transport.nsw.gov.au

Louis Tropea

Customer Service — Wollongong

Tel: 6 0843 Fax: 6 0515

Email: Louis.Tropea@transport.nsw.gov.au

Jason Cooper

Customer Service — Central

Tel: 9 2776 Fax: 9 3168

Email: Jason.Cooper@transport.nsw.gov.au

Elizabeth Wastney

Customer Service — Central and Redfern

Tel: 9 2863 Fax: 9 3114

Email: Elizabeth.Wastney@transport.nsw.gov.au

Kath Ryan

Customer Service — Wynyard, North Sydney,
Circular Quay, Milsons Point, St James and
Museum

Tel: 9 3176 Fax: 9 3103

Email: Kath.Ryan@transport.nsw.gov.au

Asset Operations**Hosh Movdawalla**

Fleet Sydney Trains

Tel: 2 0015 Fax: 2 1274

Email:

Hoshedar.Movdawalla@transport.nsw.gov.au

Goran Voca

Fleet Sydney Trains

Tel: 2 0523 Fax: 2 1274

Email: goran.voca@transport.nsw.gov.au

Richard Agostino

C and CS

Tel: 2 0875 Fax: 9 2137

Email:

Richard.Agostino@transport.nsw.gov.au

Daljit Kaur

Infrastructure Maintenance — Facilities

Tel: 2 5922 Fax: 2 5950

Email: Daljit.Kaur@transport.nsw.gov.au

Peter Shuttleworth

Systems Control Engineer

Infrastructure Operations

Tel: 9 3003 Fax: 9 1075

Email:

Peter.Shuttleworth@transport.nsw.gov.au

Helen Mardoyan

Infrastructure Maintenance — Head Office

Tel: 2 1523 Fax: 2 1306

Email: Elena.Mardoyan@transport.nsw.gov.au

Suresh Singh

Asset Planning

Tel: 2 0694

Email: Suresh.Singh@transport.nsw.gov.au

Finance and Corporate Services**Graham Church**

Compliance and Review Unit

Tel: 4 2143 Fax: 5 0321

Email: Graham.Church@transport.nsw.gov.au

Shane Brown

Network Access

Tel: 2 1203 Fax: 2 1390

Email: Shane.Brown@transport.nsw.gov.au

Human Resources**David Green**

Training — Learning and Development

Tel: 2 5944 Fax: 2 5951

Email: David.Green@transport.nsw.gov.au

Ben Hooper-Matthias

Graduates — Internships — Scholarships

Tel: 2 6540

Email:

Ben.Hooper-Matthias@transport.nsw.gov.au

NSW Trains**Dimitri Hondros**

Train Crew Manager - Central IC

Tel: 92064

Email: DIMITRI.HONDROS@transport.nsw.gov.au
[au](#)

Andrew Bailey

Train Crew Manager - Lithgow/Mt Victoria

Mob: 0428064916

Email: Andrew.BAILEY@transport.nsw.gov.au

Dale Merrick

Train Crew Manager - Newcastle/Gosford

Tel: 52364

Email: DALE.MERRICK@transport.nsw.gov.au

Suzanne Strike

Train Crew Manager - Moss Vale/Wollongong

Tel: 60602

Email: SUZANNE.STRIKE@transport.nsw.gov.au

Notice to Subscribers

The Weekly Notice is issued every Tuesday and takes effect from the following Monday.

Those who require the Weekly Notice must ensure they receive it and are aware of the changes that affect their work duties and responsibilities.

Group Manager Rules and Compliance
Sydney Trains
Level 4, 477 Pitt Street
Sydney NSW 2000
Tuesday, 6 May 2014