
Network Local Appendices

Lidcombe

Location

Lidcombe is at 16.337km.

Diagrams



Key					
1.	Down Suburban line	6.	Up Enfield West Fork line	11.	Lidcombe
2.	Up Suburban line	7.	Down Homebush Bay West Fork line	12.	Turnback road
3.	Down Main line	8.	Up Homebush Bay West Fork line	13.	Down Main South line
4.	Up Main line	9.	Shuttle road	14.	Up Main South line
5.	Down Enfield West Fork line	10.	Cemetery siding	15.	Triangle Loop line 178m

Network Local Appendices

Lidcombe

Network Control

Signaller is at Rail Operations Centre (ROC) (Lidcombe panel):

Yard Limits

Lidcombe is within Strathfield yard limits

Location details



Interlocked points are operated from ROC

17.337km Lidcombe. Platforms 0, 1, 2 and 3, 4 and 5

Level crossings



17.804 Network access

Special instructions

Nil

Related documents

NLA 110 Central-Lidcombe

NLA 114 Strathfield

NLA 116 Flemington

NLA 118 Olympic Park

NLA 200 Lidcombe-Penrith

NLA 500 Lidcombe-Campbelltown

NLA 612 Campsie-Flemington

Effective date

15 April 2024