

This is an uncontrolled copy, Before use, make sure that this is the current version by visiting <u>railsafe.org.au/rules-and-procedures/signals-and-signs/nsg-604-indicators-and-signs</u>

NSG 604 Indicators and Signs WOLO speed restriction signs

Description

Not what you are looking for? See more NSG 604 Indicators and Signs

## WOLO speed restriction signs

**WOLO** speed restriction signs are located at the locations nominated in the <u>Train Operating</u> <u>Conditions (TOC) manual</u> and are displayed while **WOLO** speed restrictions apply.

FIGURE 60: WOLO speed restriction sign.

