

## Intermediate shunting signals

### Description

Not what you are looking for? See more [NSG 602 Shunting signals](#)

---


### Intermediate shunting signals

Intermediate shunting signals are placed between two running signals, facing in the same direction as the running signals.

When the first running signal displays a **PROCEED** indication, the intermediate shunting signal displays **PROCEED** for the running movement.

An intermediate shunting signal may be used to authorise a shunting movement.

**FIGURE 6: Examples of intermediate shunting signals.**



## NSG 602 Shunting signals

### Intermediate shunting signals

