

Description

This document describes how a Special Proceed Authority must be compiled, issued, cancelled, fulfilled and managed.

Not what you are looking for? See more Form Procedures

Introduction

NRF 005 Special Proceed Authority (SPA) is used to authorise rail traffic movements when the Proceed Authority normally provided by the system of Safeworking in operation is not available.

Numbering forms

Network Controllers authorising the SPA must number the form consecutively on a pad-by-pad basis.

Mandatory items

The following items must be completed:

1 SPA Number

2 Authority

3 As a result of

4 Assurances

10 Issued to

11 Authorised by

Item 2 – Authority

Give clear details of the SPA limits as locations and/or other specified limit.

Item 3 - As a result of

Give brief and clear details about why a SPA is needed.

© Sydney Trains 2025



Item 4 – Assurances

Review each assurance and:

- write NA (Not Applicable) in the assurances box NA if the assurance has been considered but is not applicable, or
- write \mathbf{Y} (Yes) in the assurances box \mathbf{Y} if the assurance does apply.

Optional items

The following items are optional:

- 5 Worksites
- 6 Railway track signal protection
- 7 Facing points
- 8 Travelling in the wrong running-direction
- 9 Special instructions

Review each item, and:

- put a cross in the numbered box 🗶 if the item does not apply in this instance, or
- tick the numbered box 🖌 if the item applies in this instance and complete the details.

Item 5 - Worksites

If the item applies, tick the numbered box **5** and complete the details.

Record details of railway track signal protection in Item 6.

Item 6 - Railway track signal protection

If the item applies, tick the numbered box $6 \checkmark$ and complete the details.

Item 7 – Facing points

© Sydney Trains 2025



If there are points that need to be set and secured, tick the numbered box **7** c and complete the details.

Item 8 - Travelling in the wrong running-direction

Tick the numbered box **8** ✓ if the movement is in the wrong running-direction (on a unidirectional line).

Item 9 – Special instructions

Tick the numbered box **9**



FIGURE 1: NRF 005 Special Proceed Authority (SPA)

1	PA Number		
2	Authority is given to the Driver of train No. to travel on	the UP DN	line(s)
	rom YL EYL km Sig to	(cross out if not applicable)	YL EYL km Sig
	(cross out if not applicable)		(cross out if not applicable)
3	As a result of		
4	Assurances Mark each assurance box with either Y (Yes) or NA (Not A The track within the limits of this authority, excluding within yar		be occupied only by
	authorised rail traffic Affected Signallers have provided an assurance that unauthorised rail traffic is, or will be, restrained from entering the limits under		
	this authority	an dame is, or will be, resulamed nor	in entering the limits tilder
	Effective communication is established between affected Qualif	ed Workers	
	Previously issued Proceed Authorities have been cancelled or fulfilled		
	Obstructions are protected		
	Current work on track authorities or work on track methods in affected sections are cancelled or fulfilled, or worksites are protected against movements under this authority		
	Unless authorised by the Network Controller, intermediate signal boxes and local control panels in affected sections are not to switch in or out while this authority is in force		
	Qualified Workers known to be affected have been told about th	e planned movements under this a	authority
	Blocking facilities are applied		
	Drivers are, or will be, advised of any known temporary speed restriction requirements		
	The route to be taken by rail traffic is: • set and secured, or • will be set and secured	ov a Qualified Worker	
	Drivers are instructed to STOP at all active control level crossing NGE 218 Type F level crossing management. They are loca	s and treat them as potentially fau	ulty in accordance with
		km km	km km
5	Vorksites are located at:		
	km km km	km km	km km
6	tailway track signal protection has been placed at:		
		km	km km
7	pts/km pts/km pts/km pts/km pts/km	cm pts/km	pts/km pts/km
8	ravelling in the wrong running-direction: You are instructed t not exceeding 40		evailing conditions, and
9	pecial instructions and additional information		
10			
10	ssued to and read back by Driver and Signallers	train no.	hr / /
			hr / /
	name	ion/panel	hr / /
11	Authorised by Network Controller		
	name locat	ion/panel	hr / /

Related Documents

NRF-005-Special-Proceed-Authority.pdf

