

# Description

This document describes how a Pilot Staff Notice must be compiled, issued, cancelled, fulfilled and managed.

Not what you are looking for? See more Form Procedures

### Introduction

*NRF 008 Pilot Staff Notice (PSN)* is used to give details about the pilot staff working arrangements to Drivers or Track Vehicle Operators.

Signallers issue a separate PSN for every movement.

### Numbering forms

Signallers issuing a Pilot Staff Notice must number the form consecutively on a pad-by-pad basis.

# Mandatory items

The following items must be completed:

1 PSN Number

2 Pilot staff working is authorised

4 The last train

- 12 End of pilot staff working section
- 13 Issued to
- 14 Issued by

### Item 2 - Pilot staff working is authorised

Record the lines to be used for pilot staff working and the locations that mark the limits of travel on each line.

The details in this item should be the same as item 2 on NRF 008 Pilot Staff Working Introduction.



### Item 12 - End of pilot staff working section

Confirm if the end of the pilot staff working section will be defined by a signal or a **STOP** sign, and:

- tick the check box 🖌 for the item that applies
- put a cross in the other check box X.

If a signal is used as the end of the section, give the designation, number, and location.

If a **STOP** sign is used as the end of the section, give the location.

# **Optional items**

The following items are optional:

- 3 Half-staff
- 5 Active control level crossings
- 6 Block posts
- 7 WARNING signs
- 8 Worksites
- 9 Facing points
- 10 Signals at STOP
- 11 Special instructions and additional information

Review each item, and:

- put a cross in the numbered box 🗶 if the item does not apply in this instance, or
- tick the numbered box 🖌 if the item applies in this instance and complete the details.

#### Item 8 - Worksites

If the item applies, tick the numbered box **8** and complete the details.

If during pilot staff working, rail traffic has to pass six or fewer worksites, complete the worksite details.

© Sydney Trains 2025



If rail traffic has to pass more than six worksites:

- tick the check box 🖌 beside 'There are more than six worksites', and
- do not give any details of the worksites on the PSN, and
- give details about the worksites on an *NRF 011 Worksite Warning*.

#### Item 9 – Facing points

If there are points that need to be set and secured, tick the numbered box **9** and complete the details.

#### Item 10 – Signals at STOP

If authorisation is not given to pass signals at STOP, put a cross in the numbered box 10 x.

If permission is given to pass signals at **STOP** without further authorisation:

- tick the numbered box **10**, and
- detail the signals. The signals must not include signals used as a block post location, and
- give full details of the first operating signal to be obeyed.

### Item 11 – Special instructions and additional information

If the item applies, tick the numbered box **11 /** and record information about special instructions or additional information such as:

- additional WARNING signs
- other speed restrictions
- other conditions.



#### FIGURE 1: NRF 008 Pilot Staff Notice (PSN)

1	PSN Number			7			
2	Pilot staff working	is authorized	onthe				
-		15 dution Scu	line from		location to		location
	UP DN		line from		location to		location
	UP DN		line from		location to		location
	UP DN		line from		location to	<u>.</u>	location
	oss out if not applicable)						
3	Half-staff for the oth		on has been rem				location/km
4	The last train cleare			location at	hr		
5	Active control leve	I crossings are p	protected and H km	andsignallers provided. Th	ey are located at	:: km	km
			NII		NIII		NII
6	Block posts are locat				/lon		location /low
		location/kr		location	12 Kill		location/km
7	Warning signs are lo	ocated at: location/kr	n	location	Xkm		location/km
•	Worksitz						Le Suerenz Kill
8	Worksites are locate	location/kn		location/ki	a maximum s	need of	km/h applie
	from	location/kn		location/ki	-	-	km/h applie:
	from	location/kn		location/ki	_		km/h applie
	from	location/kn		location/ki	_	-	km/h applie
	from	location/kn		location/ki	-	· · · · · · · · · · · · · · · · · · ·	km/h applie
	from	location/kn		location/ki	-		km/h applie
	There are more that						
9	Facing points you a						
	pts/km	pts/km	pts/km	pts/km	pts/km	pts/km	pts/km
10	Signals at STOP you	are authorised to	pass:				
_	Sig	Sig	Sig	Sig	Sig	Sig	Sig
	The first operating sign	al you must obey is		Sig	designation	Sig	km
11	Special instruction						
12	End of the pilot sta	off working sec			] [		
	Signal STOP sign		Sig design locatio		k	m	
13	Issued to Driver/T	rack Vahicla O		17.811			
15	issueu to Driver/ I	name	perator	rail traffic ID	]		
14	Issued by Signaller	· · · · · · · · · · · · · · · · · · ·					
		name		location/panel		hr /	/

# **Related Documents**

#### NRF-008-Pilot-Staff-Notice-PSN.pdf

